
REVISED PACKET TRACER

Prerequisite: Given the following network toplogy:



RouterO#show ip dhcp pool


Pool MY LAN :

Utilization mark (high/low) : 100 / 0
Subnet size (first/next) : 0 / 0
Total addresses : 254
Leased addresses : 3
Excluded addresses : 1
Pending event : none


1 subnet is currently in the pool

Router0#

In this practice, we change the DHCP server role on the router to a PC server.




1. Revoke DHCP server function from the router Verify the current status



```
show ip dhcp pool
Pool MY LAN :
Utilization mark (high/low) : 100 / 0
Subnet size (first/next) : 0 / 0
                            : 254
Total addresses
                            : 0
Leased addresses
Excluded addresses
                            : 1
Pending event
                            : none
1 subnet is currently in the pool
                   Current index IP address range
192.168.1.1
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config) #no ip dhcp pool MY LAN
Router(config) #exit
```


```
Router#
%SYS-5-CONFIG_I: Configured from console by console
show ip dhcp pool
Router#
```

Then, we can use the command (in "configure terminal") to delete DHCP Pool: no ip dhcp pool MY_LAN After deleteing, we can re-verify to show that the pool is gone.




2. Add a generic server and enable DHCP server:

Add the server and another subnet with one PC and one Server as following topology



Click on Server to enable DHCP server.

Set the static IP address for each server Fast Ethernet0 (use "configure terminal" as in Lab 1) or the GUI interface




Add the 2 DHCP service to the two server following this setting.

Server	IP	Subnet mask	Default Gateway	DNS server
Server 0	192.168.15.5	255.255.255.0	192.168.15.1	192.168.15.10
Server 1	192.168.1.5	255.255.255.0	192.168.1.1	192.168.1.10

Start IP Address:

Server 0: Start IP address 192.168.15.100 Subnet mark 255.255.255.0 MaxNoUser:127

Server 1: Start IP address 192.168.1.100 Subnet mark 255.255.255.0 MaxNoUser:127



Recall the DHCP client setting for each PC and then re-apply the ping to check the network connection.

In this practice, the two IP subnet is not seen by each other. The further practice will help setting to make them connected.